

SPF 5000TL HVM Off Grid inverters with lead acid battery Settings Introduction

1st option: Output source Priority

Utility first (default)	Utl	01	
Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available.			

Solar first	SOL	01	
Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power the loads at the same time. Utility provides power to the loads only when any one condition happens: - Solar energy is not available - Battery voltage drops to either low-level warning voltage or the setting point in program 12.			

If you want to make full use of solar energy. The option can be chose.

Low level warning : 21th option plus 2V

SBU priority	SbU	01	
Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.			

If you want to make full use of battery energy. The option can be chose.

2nd option: Charging current

02	Maximum charging current: To configure total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current)	80^ 02	48V 5KVA/4KVA model:default 60A, 10A~140A settable 48V 3KVA/2KVA MPPT model:default 30A, 10A~45A settable 48V 3KVA/2KVA PWM model:default 65A, 10A~65A settable 48V 3KVA/2KVA MPPT model:default 60A, 10A~80A settable 24V 3KVA/2KVA PWM model:default 80A, 10A~80A settable (If Li is selected in program 5,this program can't be set up)
----	---	--------	---

For lead acid battery, the charging current should be 0.2-0.3C for single battery (C means battery capacity). If you have several batteries, 0.2-0.3C*quantity of batteries. Is charging current.

3rd option: AC input voltage range

03	AC input voltage range	APL 03 Appliance (default)	If selected, acceptable AC input voltage range will be within 90~280VAC
		UPS 03 UPS	If selected, acceptable AC input voltage range will be within 170~280VAC
		GEN 03 Generator	If selected, acceptable AC input voltage range will be within 90~280VAC

If you utility input is not stable, you can choose GEN 03, it accepts wide voltage range. Or unstable voltage will affect inverter.

Fourth option:

04	Power saving mode enable/disable	Sd5 04 Saving mode disable (default)	If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected.
		SEN 04 Saving mode enable	If enabled, the output of inverter will be off when connected load is pretty low or not detected.

Default value is Sd5, If it is enabled, when the load is lower than 150W, inverter will stop AC output. Please highlight the point.

5th option:

05	Battery type	AGM (default) AGM 05	User-Defined USE 05
		Flooded FLD 05	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 19, 20 and 21.
		Lithium LI 05	
(Only suitable when communicated with BMS)			

For AGM lead acid battery, You can use AGM or USE.

For FLD lead acid battery, you can use FLD

For Gel lead acid battery, you can use AGM or USE

If USE-Defined is selected, 19th, 20th, 21th can be modified.

6th option:

06	Auto restart when overload occurs	Restart disable (default) LFD 06	Restart enable LFE 06

Default value is ok.

7th option:

07	Auto restart when over temperature occurs	Restart disable (default) LTD 07	Restart enable LTE 07

Default value is ok.

8th option:

08	Output voltage	230V (default) 230V 08	220V 220V 08
		240V 240V 08	208V 208V 08

Default value is ok.

9th option:

09	Output frequency	50Hz (default) 50.09	60Hz 60.09
----	------------------	-------------------------	---------------

Default value is ok.

10th option:

10	Number of series batteries connected		
----	--------------------------------------	--	--

It is fixed value. It means that your inverter matches 24V or 48V battery system. 48V will show 4, 24V will show 2.

11th option:

11	Maximum utility charging current	30 ^A	11
----	----------------------------------	-----------------	----

48V model: default 30A, 10A~60A Settable(4KVA/5KVA)
 24V model: default 20A, 20A~30A Settable(2KVA/3KVA)
 48V model: default 10A, 10A~15A Settable(2KVA/3KVA)
 (If Li is selected in program 5, this program can't be set up)

Set max utility input charging current.

If Li is selected in program 5, it can't be modified.


12th option:

12	Setting voltage point back to utility source when selecting "SBU priority" or "Solar first" in program 01	46.0 ^v	12	
----	---	-------------------	----	--

48V model: default 46.0V, 44.0V~51.2V Settable
 24V model: default 23.0V, 22.0V~25.6V Settable

It is used to set the battery voltage point that comes back to utility input. If battery voltage is lower than the voltage point, it will transfer to utility input and charge the battery.

13th option:

13	Setting voltage point back to battery mode when selecting "SBU priority" or "Solar first" in program 01	540 ^v	13	
		48V model: default 54.0V, 48.0V~58.0V Settable 24V model: default 27.0V, 24.0V~29.0V Settable		

It is used to set the battery voltage point that comes back to battery supply. If battery voltage is higher than the voltage point, it will transfer to battery mode.

14th option:

14	Charger source priority: To configure charger source priority	If this off grid solar inverter is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar first C50 14	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
		Utility first CUT 14	Utility will charge battery as first priority. Solar energy will charge battery only when utility power is not available.
		Solar and Utility SNU 14	Solar energy and utility will both charge battery.
		Only Solar 050 14	Solar energy will be the only charger source no matter utility is available or not.
		If this off grid solar inverter is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	

It is battery charging source priority.

C50 means solar first, Solar energy will charge the battery as first priority. Utility input will charge battery only when solar energy is not available.

CUT means Utility first, utility will charge the battery as first priority. Solar energy will charge battery only when utility power is not available.

SNU means both solar energy and utility will charge battery.

050 means solar energy will be the unique charging source no matter utility input is available or not.

15th option:

15	Alarm control	Alarm on (default)	Alarm off
		bUZZ ON 0 15°	bUZZ OFF 0 15°

Default value is ok.

16th option:

16	Backlight control	Backlight on (default)	Backlight off
		LCdb ON 0 16°	LEdb OFF 0 16°

Backlight of LCD. Default value is ok.

17th option:

17	Beeps while primary source is interrupted	Alarm on (default)	Alarm off
		ALAr ON 0 17°	ALAr OFF 0 17°

Primary source means Solar power.

18th option:

18	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default)	Bypass enable
		bYP dI S 0 18°	bYP ENR 0 18°

Line mode means utility input mode. When overload occurs on battery mode, inverter will switch to utility input.


19th option:

19	Bulk charging voltage (C.V voltage). If self-defined is selected in program 5, this program can be set up	C.V 56.4V 0 19°
		Default: 56.4V, 48.0V~58.4V Settable

For lead acid battery, normal voltage should be

Charging voltage 56-58V

20th option:



20	Floating charging voltage. If self-defined is selected in program 5, this program can be set up	
----	---	--

Floating voltage range: for lead acid battery , it is almost 54V.






21th option:

Low DC cut-off voltage means when the battery voltage reaches cut-off voltage, inverter will shut off automatically so that it can protect battery system.


22th option:

22	Solar power balance. When enabled, solar input power will be automatically adjusted according to connected load power.	Solar power balance enable (Default): 	If selected, solar input power will be automatically adjusted according to the following formula: Max. input solar power = Max. battery charging power + Connected load power.
		Solar power balance disable: 	If selected, the solar input power will be the same to max. battery charging power no matter how much loads are connected. The max. battery charging power will be based on the setting current in program 2. (Max. solar power = Max. battery charging power)

23th option:

23	AC output mode *This setting is only available when the inverter is in standby mode (Switch off).	Single: 	Parallel: 
		L1 Phase: 	L2 Phase: 
		L3 Phase: 	
		When the units are used in parallel with single phase, please select "PAL" in program 23. It requires 3 inverters to support three-phase equipment, 1 inverter in each phase. Please select "3P1" in program 23 for the inverters connected to L1 phase, "3P2" in program 23 for the inverters connected to L2 phase and "3P3" in program 23 for the inverters connected to L3 phase. Be sure to connect share current cable to units which are on the same phase. Do NOT connect share current cable between units on different phases. Besides, power saving function will be automatically disabled.	

Only when inverters are working in parallel on different phase, the option can be set. When setting it, make sure AC switch on the bottom is off.



24th option:

24	Allow neutral and grounding of AC output is connected together: When enabled, inverter can deliver signal to trigger grounding box to short neutral and grounding (for expansion)	Disable: Neutral and grounding of AC output is disconnected. (Default)
		d r y d i s 0 2 4 °
		Enable: Neutral and grounding of AC output is connected.
		d r y E N A 0 2 4 °
		This function is only available when the inverter is working with external grounding box. Only when the inverter is working in battery mode, it will trigger grounding box to connect neutral and grounding of AC output.